

FEATURES

- Asynchronous serial data transmission
- Automatic baud-rate fitting up to 115.2 Kbps
- Distance up to 1200 m
- Point to point connection or multipoint connection up to 32 modules
- DC or AC power supply
- Galvanic isolation on all ways
- RS232 connection on DB9 or removable terminals
- EMC compliance – CE mark
- Suitable for DIN rail mounting in compliance with EN-50022



GENERAL DESCRIPTION

The device SS3580 is an isolated interface converter between asynchronous serials lines RS232 and RS485 or RS422 that guarantees a full isolation between power supply, serial line RS-232 and serial line RS-485 or 422 removes eventual ground-loop effects, allowing the use of the device even in the heavy environmental conditions.

It is designed to operate either on serial interface RS-422 full-duplex 4 wires or RS485 half-duplex 2 wires, with a baud-rate transmission up to 115.2 Kbps.

The transmission is asynchronous without settings of protocol, data format and baud rate.

On the line RS-232 are not necessary handshake commands (RTS, CTS, etc..) to control the baud rate.

SS3000 series devices are designed to be easily mounted on DIN rail, optimizing the space encumbrance. Whereas the thermal dissipation allows it, the devices can be mounted side by side, allowing a relevant reduction of space requiring. The connections are made by means of removable screw terminals, to simplify the handling of the devices.

The SS 3580 is in compliance with the 89/336/EEC directive on the electromagnetic compatibility.

The device is housed in a rough self-extinguishing plastic container which, thanks to its thin profile of 22.5 mm only, allows a high density mounting on EN-50022 standard DIN rail.

USER INSTRUCTIONS

Before to install the device, please read the "Installation Instruction" section.

The device SS3580 converts the serial transmission from RS-232 to RS-485 (2 wires) or RS-422 (4 wires) as follows.

The data incoming from the line TX of RS-232 (DB9 connector pin 3) are converted and transmitted to the terminals D-E of RS-485 and RS-422.

The data incoming from the line RX of RS-485 (terminal D and E) or RS-422 (terminal B and C) are converted and transmitted to the terminal RX of RS-232 (DB9 connector pin 2).

The transmission of the signal follows the logic state of every single bit, then there is not necessary to set the protocol, the data format and the baud-rate.

When the transmission line from the RS-232 is off, the RS-485 driver is in the receive condition (high impedance); when the transmission line from the RS-232 goes on, the RS-485 driver switch immediately to the transmission condition (low impedance). The low impedance is kept for about 150 us, then the line returns automatically in high impedance (receiver).

TECHNICAL SPECIFICATIONS (Typical @ 25 °C and in the nominal conditions)

| | | | |
|---|--|-----------------------------------|---|
| In compliance with | EIA RS232, RS485 and RS422 | Power Supply | 10 ÷ 30 Vdc 9 ÷ 18 Vac (18 ÷ 30 Vac optional) |
| RS485 Interface | | Current consumption | 35 mA typ. @ 24Vdc |
| Baud-rate | up to 115.2 Kbps | Isolations | |
| Max. distance / baud-rate ratio (recommended) (1) | 1,2 Km @ 38400 bps 2 Km @ 19200 bps 3 Km @ 9600 bps 4 Km @ 4800 bps 5 Km @ 2400 bps 7 Km @ 1200 bps | Power supply / RS232 | 2000 Vac, 50 Hz, 1 min. |
| | | Power supply / RS485-422 | 2000 Vac, 50 Hz, 1 min. |
| | | RS232 / RS485-422 | 2000 Vac, 50 Hz, 1 min. |
| Number of modules in multipoint | up to 32 | EMC | |
| Switching time TX/RX (RS485) | 150 us. | Immunity | EN 61000-6-2 |
| Internal terminator resistance (optional) | 120 Ohm | Emission | EN 61000-6-4 |
| | | Temperature & Humidity | |
| | | Operative temperature | -20 ÷ +60 °C |
| | | Storage temperature | -40 ÷ +85 °C |
| | | Relative humidity (not condensed) | 0 ÷ 90 % |
| | | Connection | |
| | | RS-232 | DB9 and removable screw terminals |
| | | RS-485/422 | removable screw terminals |
| | | Housing | |
| | | Material | Self-extinguishing plastic |
| | | Mounting | DIN rail in compliance with EN-50022 |
| | | Dimensions in mm.(W x H x T) | 100 x 120 x 22.5 |
| | | Weight | about 160 gr. |

(1) – The maximum distance depends of: number of devices connected, type of cabling, noises, etc...

INSTALLATION INSTRUCTIONS

The SS 3580 device is suitable for fitting to DIN rails in the vertical position. For optimum operation and long life follow these instructions:


When the devices are installed side by side it may be necessary to separate them by at least 5 mm in the following case:

- If panel temperature exceeds 45°C and high power supply value(> 27Vdc).

Make sure that sufficient air flow is provided for the device avoiding to place raceways or other objects which could obstruct the ventilation slits. Moreover it is suggested to avoid that devices are mounted above appliances generating heat; their ideal place should be in the lower part of the panel. Install the device in a place without vibrations.

Moreover it is suggested to avoid routing conductors near power signal cables (motors, induction ovens, inverters, etc...) and to use shielded cable for connecting signals.


CABLING




LIGHT SIGNALLING

| LED | COLOUR | STATE | DESCRIPTION |
|-----|--------|-------------|--|
| PWR | GREEN | ON | Device powered |
| | | OFF | Device not powered / Wrong RS-485 cabling. |
| | | RAPID BLINK | Communication in progress (blink frequency depends to baud-rate) |


DIMENSIONS (mm)



WIRING



ISOLATION STRUCTURE



HOW TO ORDER

In phase of order it is necessary to specify the type of interface (RS485 or RS422) and, if required, the 24Vac power supply option.

SS 3580 / **2W** / **24**

Type of interface:
2W: RS-485 (2 wires)
4W: RS-422 (4 wires)

AC power supply option:
24 : 24Vac (18+30Vac)

■ = Requested
□ = Optional