

The device SS10015 converts up to 8 analogue input signals into engineering units in digital format. The data are transmitted with MODBUS RTU/ASCII protocol over the RS-485 network. It is possible to connect on input 4 voltage signals up to ± 10 V and 4 current signals up to ± 20 mA. By programming, it is possible to execute the scaling of the

It is possible to connect on input 4 voltage signals up to ± 10 V and 4 current signals up to ± 20 mA. By programming, it is possible to execute the scaling of the measure of input up to ± 32768 points obtaining in the dedicated registers the measure of the channel in the desired format. The device guarantees high accuracy and stable measure versus time and temperature.

The device guarantees high accuracy and stable measure versus time and the number of the plant safety, a Watch-Dog timer alarm is provided.

The isolation between the parts of circuit removes eventual ground-loop effects, allowing the use of the device even in the heavy environmental conditions.

The device is housed in a 6 module DIN rough self-extinguishing plastic box for mounting on EN-50022 standard DIN rail.

COMMUNICATION PROTOCOLS

The device is designed to work with the MODBUS RTU/ASCII protocol: standard protocol in field-bus; allows to directly interface SS10000 series devices to the larger part of PLCs and SCADA applications available on the market.

USER INSTRUCTIONS

Before to install the device, please read the "Installation Instruction" section.

It is possible to configure the device in two modes: by the dip-switches located on the front of the device or via software using the INIT modality.

Connect the terminal INIT to the terminal REF; at the power-on the device will be automatically set in the configuration set-up.

Connect power supply, serial bus and analogue inputs as shown in the "Wiring" section.

The LEDs state depends on the working condition of the device: see the "Light Signalling" section to verify the device working state.

To simplify handling or replacing of the device, it is possible to remove the wired terminals even with the device powered.

TECHNICAL SPECIFICATIONS (Typical @ 25 °C and in the nominal conditions)

INPUT			Input Accuracy (1)		POWER SUPPLY	
Input type	Min	Мах	Current Voltage	± 20 uA ± 10 mV	Power supply voltage Reverse polarity protection	10 30 Vdc 60 Vdc max
Current 20 mA	-20 mA	+20 mA	Linearity (1)	± 0.1 % f.s.	Current consumption (operative) 35 mA max@24Vdc 45 mA max@10Vdc	
Voltage 10 Volt	-10 V	+10 V	Input impedance Current Voltage	<= 50 Ω >= 1 ΜΩ	ISOLATION Between all the ways	1500 Vac, 50 Hz, 1 min
			Thermal drift (1) Full scale	± 0.005 % / °C	ENVIRONMENTAL CONDI Operative Temperature Storage Temperature	-10°C +60°C -40°C +85°C
			Sample time	0.5 ÷ 1 sec.	Humidity (not condensed)0 90 %Maximum Altitude2000 m	
			Data Transmission (RS-48 Baud Rate Max. distance	5 asynchronous serial) 115.2 Kbps 1.2 Km – 4000 ft	Installation Category of installation Pollution Degree	Indoor II 2
					MECHANICAL SPECIFICA Material IP Code Wiring Tightening Torque Mounting Weight	TIONS Self-extinguish plastic IP20 wires with diameter 0.8÷2.1 mm ² /AWG 14-18 0.5 N m in compliance to DIN rail standard EN-50022 about 200 g.
					CERTIFICATIONS EMC (for industrial envir Immunity Emission	ronments) EN 61000-6-2 EN 61000-6-4
(1) referred to the input	Span (difference betwe	en max. and min.)				

INSTALLATION INSTRUCTIONS

The SS10015 is suitable for fitting to DIN rails in the vertical position. For optimum operation and long life follow these instructions:


When the devices are installed side by side it may be necessary to separate them by at least 5 mm in the following case:

- If panel temperature exceeds 45°C and power supply voltage 10 Vdc.

Make sure that sufficient air flow is provided for the device avoiding to place raceways or other objects which could obstruct the ventilation slits. Moreover it is suggested to avoid that devices are mounted above appliances generating heat; their ideal place should be in the lower part of the panel. Install the device in a place without vibrations.


Moreover it is suggested to avoid routing conductors near power signal cables (motors, induction ovens, inverters etc...) and to use shielded cable for connecting signals.






LIGHT SIGNALLING

LED	COLOUR	STATE	DESCRIPTION
PWR	GREEN	ON	Device powered
		OFF	Device not powered
		BLINK	~1 sec Watch-Dog alarm condition occurred
RX	ORANGE	BLINK	Stream of data over receiving line of RS-485
		OFF	No data over receiving line of RS-485
ТΧ	ORANGE	BLINK	Stream of data over transmission line of RS-485
		OFF	No data over transmission line of RS-485



CONNECTIONS




NOTE: the input channels are not isolated between them (terminal GND is common)


SERIAL LINE RS-485

POWER SUPPLY

V+

V-






ISOLATION STRUCTURE



DIP-SWITCHES : TABLES OF CONFIGURATION

Warning: set all the dip-switches in OFF position to access to the device in EEPROM modality (the device will follow all the communication parameters set by software) or INIT. Power-off the device before to change the set of the dip-switches.



HOW TO ORDER SS10015